

# AA1300 Tailwheel Assembly

## Four Methods of fixing

1. Allow to self centre by using a rubber band or spring. Bend a loop in the tailwheel wire as required.

2. Steerable, using wire bent at 90 degrees into rudder and use adhesive.

3. Non steerable, fixed into fuselage with adhesive.

4. Floating, cut wire and fit 16swg collet above nylon bracket.

16SWG SPRING STEEL WIRE ALUMINIUM SPACER  
16SWG END FASTENER 19, 25, 30 DIA. TAILWHEEL  
No 2x3/8 SCREWS, NYLON TAILWHEEL BRACKET  
THREE HOLES IN WEB FOR SECURE ATTACHMENT  
AND ADHESIVE LOCATION